

INFINITY EVOLUTION QUICK START GUIDE

USING THE VOICE CONTROL FEATURE

To activate the voice control feature, select MENU > SETTING > VOICE > ON. Then, touch the button on the left speaker, or say "Switch to voice mode" to complete voice control activation.

Use the voice control commands below. (Once you've activated voice control, give a command within 5 seconds, or you will have to re-activate the voice function.)

- ▶ Switch to voice mode
- ▶ Power On
- ▶ Switch Off
- ▶ Activate Massage
- ▶ Sports Refresh
- ▶ Extension
- ▶ Rest & Sleep
- ▶ Working Relief
- ▶ Neck & Shoulder
- ▶ Waist & Spine
- ▶ Airbag Massage
- ▶ Deep Shiatsu
- ▶ Healthy Breath
- ▶ Massage Extend
- ▶ Zero Gravity
- ▶ Start Heat
- ▶ Heat Off

INFINITY EVOLUTION QUICK START GUIDE



Please contact Technical Support at
603-910-5000 with any questions or concerns, or watch our
helpful tutorials at www.youtube.com/infinitymassagechairs.




72 Stard Road, Seabrook, NH 03874
603-910-5000
www.infinitymassagechairs.com

INFINITY EVOLUTION QUICK START GUIDE

- 1 **MULTI-FUNCTION SCREEN:** Menu options and massages appear on this screen.
- 2 **ON/OFF:** Use this button to turn the chair on and off.
- 3 **MENU:** Press this button in the main interface to switch to the menu to set functions of the massage chair. Press again when in menu to return to main screen.
- 4 **SHOULDER POSITION:** Use this option to adjust the position of the massage in manual and point mode.
- 5 **AUTO:** Use this button to switch auto programs. Each time you click this button, you will select a new auto program. Adjust your massage time by selecting MENU > SETTING > TIME (options are 10, 20, or 30 minutes).

- ▶ **Sports Refresh:** Recover after a physically-demanding day with this strenuous and invigorating full-body massage.
- ▶ **Extension:** Revive and revitalize your system with a gentle full-body massage.
- ▶ **Rest & Sleep:** Enjoy this gently soothing full-body massage created to relieve stress, decompress your body, and prepare you for sleep.
- ▶ **Working Relief:** Relieve sore muscles with a soothing moderate rub-down featuring air pressure massage for the neck and shoulders.
- ▶ **Neck & Shoulder:** Relax with a full-body massage focusing on stress and tension relief in your upper body.
- ▶ **Waist & Spine:** Realign and correct your spine to reduce pressure and improve posture.
- ▶ **MyMassage:** To save customized massages, simply choose your settings under the MANUAL menu, and then run the massage. Next, under the AUTO menu, scroll down and select either MyMassage 1 or MyMassage 2. Here, you have the option to Save the current manual massage, or Run a saved custom massage.

- 6 **DIRECTIONAL BUTTON:** In the menu, select Auto mode, then click the up, down, left, and right buttons to choose the function, and click "OK" to confirm.



- 7 **FEET ADJUST:** Use these buttons to raise and lower the legrest.
- 8 **BACK ADJUST:** Use these buttons to recline and raise the seat back.
- 9 **3D BUTTON:** Push this button to adjust the 3D intensity. See 3D on multi-function screen to adjust.
- 10 **FEET EXTEND:** Press this button to extend the foot rest. Release button to stop.
- 11 **FEET RETRACT:** Press this button to retract the foot rest to the original position. Release button to stop.

3D MASSAGE

Press MENU, then choose 3D Massage. Select from 3D MODE options:

- ▶ **Deep Shiatsu:** Deep shiatsu on the back for 10 mins.
- ▶ **Healthy Breath:** 5 mins. of healthy breath massage with rhythm to assist with breathing in and out.
- ▶ **Massage Extend:** 5 mins. of massage and extension

MANUAL MASSAGE

Press MENU, then select MANUAL to select from one of the following massage styles: Kneading, Tapping, Knocking, Shiatsu, or Sync.

ADDITIONAL MANUAL MASSAGE TIPS

- ▶ Activate the foot rollers by pressing MENU > MANUAL > ROLLER. You can choose from 3 speeds in this menu.
- ▶ Select MENU > HEAT to activate the lumbar heat. Allow a few minutes to feel the full benefits.
- ▶ Select MENU > LANGUAGE to set the preferred language for the menus.
- ▶ Select MENU > AIRBAG to adjust functioning airbag zones. Options are Full, Arm & Shoulder, Back & Waist, Leg & Foot and Buttock.